

GLAST Calorimeter

*Paris Cal Mtg.
14-16 Feb 2000*


CsI Crystal Processing Summary

February 2000

J. Eric Grove
Naval Research Lab

Naval Research Lab
Washington DC






GLAST Calorimeter

CsI Crystal Processing

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Acceptance testing.
 - inspection, metrology.
 - light yield vs position w/ ^{22}Na source (PMT dry mount, both ends).
- ❑ Surface processing (Ukrainian crystals only, Crismatec delivered with light taper).
- ❑ Crystal resizing (Ukrainian only).
- ❑ End treatment.
 - a) blacken with aperture for PIN photodiode or
 - b) white Tetrtek.
- ❑ Light yield vs position w/ ^{22}Na source.
- ❑ Mount PIN photodiodes.
- ❑ Final optical wrap.
 - Tetrtek (2 x 10 mil).
 - Aluminized mylar with adhesive.
- ❑ Muon testing (and ^{228}Th source).






Beam Test Calorimeter Prototype CsI Status

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ All 90 CsI crystals (310 x 30 x 23 mm) have been received and acceptance-tested at NRL.
 - 40 Crismatec, 50 Amcrys-H (Ukraine).
- ❑ 10 40-cm crystals have been received from Ukraine.
 - 6 have been cut to 37 cm and surface-treated. Sent to France.
- ❑ Ukrainian crystals were delivered with fine polish. We applied light taper.

- ❑ Visual inspection
 - Crismatec:
 - Clear as glass. Typically one or two small, dark inclusions. Rare internal crystal flaws, crystal boundaries.
 - Fine polish on ends and two surfaces. Occasional small surface flaws. Scratches, chips.
 - Ukrainian:
 - Milky. Typically one or two dozen small, dark inclusions. Occasional internal crystal flaws, crystal boundaries, small cracks.
 - Surface polish is not as fine as Crismatec. All have thin smudge line from adhesive in wrapper. Occasional surface flaws, scratches, pits, chips, cracks, crystal boundaries, goobers.





GLAST Calorimeter

Crystal Metrology

Paris Cal Mtg.
14-16 Feb 2000

□ Metrology summary

- Bars are typically too large in cross section by ~0.1 mm.
- Large-scale (> few cm) surface variations of order 0.1 mm.
- Crismatec crystals are superior to Ukrainian. Dimensions are closer to spec. Surface variations are smaller in height. e.g. one Ukrainian is warped by ~0.3 mm.

Worst crystal: Ukrainian U-02-21.


Units are mm.


Contours are 0.02 mm.

Red: More than ± 0.1 mm from spec.

Black: 0.0 to +0.1 mm from spec.

Blue: -0.1 to 0.0 mm from spec.







GLAST Calorimeter

Crystal Testing Station

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ Map crystal response as a function of position.
 - ^{22}Na source scanned along length of crystal.
 - Red-sensitive PMTs at both ends.
 - Hamamatsu R669.
- ❑ Fully automated scanner acquires map in 40 minutes.
- ❑ IDL analysis s/w fits 1275 keV peak and generates map hardcopy.






GLAST Calorimeter

Crystal Test Procedure


Paris Cal Mtg.
14-16 Feb 2000

- ❑ Crystals are numbered and inspected as delivered.
 - Factory wraps are Teflon-only or Tyvek and aluminum foil.
 - Additional wrap of aluminized mylar is added if necessary.
- ❑ Various end treatments may be applied as required for test.
- ❑ Crystal is mounted between two R669 2" PMTs.
 - Air gap between crystal and PMT.
- ❑ ^{22}Na or ^{137}Cs source is scanned along crystal with motor drive.
- ❑ **Good spectroscopy is achieved.**



Naval Research Lab
Washington DC







GLAST Calorimeter

CsI Light Tapering Crismatec Material

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ ^{22}Na source scanned along length of crystals.
- ❑ Crystals arrive from factory scanned from one end. We scan simultaneously from both ends.
- ❑ Crismatec crystal with factory surface treatment and factory wrap.
 - Open symbols: factory testing.
 - Filled symbols: NRL testing.
 - Normalized to mean response.







GLAST Calorimeter

Surface treatment of Amcrs

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Ukrainian bars arrive with “fine” polish.
 - Light collection ~ uniform, varies by dopant.
 - (red and black curves, open symbols).
- ❑ NRL surface treatment gives tapering equivalent to Crismatec.
 - (red and black curves, filled symbols).
 - Treatment leaves absolute light yield ~ unchanged.
 - Can tune treatment to give desired slope.
 - Bars with slope too steep can even be flattened!






GLAST Calorimeter


Light Tapering Total Light vs Position

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ Tapered bars still give good energy resolution:
Sum of two ends is nearly constant.
- ❑ Crismatec from factory and Ukrainian after surface treatment achieve similar performance.

Ukrainian U-02-28 after surface and end treatments.






GLAST Calorimeter


Diode Bonding

*Paris Cal Mtg.
14-16 Feb 2000*

Diode bonding fixture

- ❑ Six identical stations.
 - Crystal held vertically.
 - Nylon pins maintain crystal alignment.
 - Nylon block at base of fixture holds PIN diode in place.
 - Pre-measured amount of Epotek delivered to PIN.
 - Weight of crystal provides standard pressure on diode bond.





GLAST Calorimeter


Crystal Wrapping


*Paris Cal Mtg.
14-16 Feb 2000*

Processing of CsI crystals.

After acceptance testing
in temporary wrap.
After PIN diodes are
glued on the ends.

Final wraps of Tetrakel
and aluminized Mylar
are applied.






GLAST Calorimeter

Muon Telescope

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ Muon telescope.
- ❑ Stack 20 crystals at once.
 - 10 in x and 10 in y.
 - eV5093 preamps.
 - Crystal geometry naturally defines 10 longitudinal bins for each crystal.
- ❑ 2-dimensional wire chambers above and below provide trigger and finer muon tracking.







GLAST Calorimeter

Muon Telescope

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ Telescope assembly.
 - 2D wire chamber.
 - Crystal housing.
 - 2D wire chamber.
- ❑ CAMAC data acquisition system.
- ❑ IDL analysis s/w fits muon peaks and generates map hardcopy.
- ❑ Telescope can be expanded to accommodate full calorimeter tower.







GLAST Calorimeter

Final Performance

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Crystals with final surface and end treatments achieve excellent performance with custom dual PIN.
- ❑ Ukrainian crystal.
- ❑ Spectrum of ^{228}Th in 1 cm^2 custom dual-PIN.
- ❑ Factory wrap.
 - Tyvek with aluminum foil.
 - Tetratek gives ~20% more light.
- ❑ Laboratory bench electronics.







GLAST Calorimeter

Distribution of Light Yields

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Light yield of Crismatec and Amcrys bars, with final surface treatment and final wrap.
 - Variation from bar to bar is small.
 - rms light yield in big PIN = 4%.
 - Crismatec and Amcrys bars are *indistinguishable*, despite the obvious difference in optical opacity: Crismatec bars are clear, while Amcrys bars are milky!
 - Mean yield
 - in 1-cm² PIN = 3000 e/MeV.
 - in ¼-cm² PIN = 750 e/MeV.
 - Note crystals with low yields in small PIN...







GLAST Calorimeter

Distribution of Light Yields

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Some optical bonds to small PIN were poor.
 - Poor bonds not detected in bench checkout because ^{228}Th photopeak is not detectable in small PIN.
 - Next time: check all bonds with muons immediately.
 - Fractional difference in yield in small PIN relative to corresponding big PIN:
 - $f = (4Y_S - Y_B) / Y_B$
 - Factor of 4 accounts for difference in geometric area.
 - Rejected crystals based on this ratio, or placed them in top of BTEM calorimeter, where small PIN is less useful.







Distribution of Slopes (Light Attenuation Lengths)

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Fit linear model to light yield as a function of position for each end of crystal.
- ❑ Crismatec and Amcrys bars with final surface treatment and wrap.
 - Mean slope = 1.5% per cm
 - rms of slope = 0.3% per cm (20% of mean slope)
 - Mean slope corresponds to end-to-end attenuation of ~ 0.4 , i.e. response at far end is 40% of response at near end.





GLAST Calorimeter

*Paris Cal Mtg.
14-16 Feb 2000*

CsI Testing and Trade Studies

J. Eric Grove


Radiation damage

Detector packaging: wraps or paints

Pressure testing on wraps

End treatments: white or black





GLAST Calorimeter

Radiation Damage


Paris Cal Mtg.
14-16 Feb 2000


❑ NRL's ^{60}Co Irradiation Facility

- Dose rate ~50-200 Rad per hour.
- Horiba 240 x 30 x 25 mm crystal.
- S3590 PIN readout on both ends.
- Results consistent with Woody et al. (BNL reprint).
- Degradation caused by decrease in effect light attenuation length.

❑ Estimated on-orbit dose <1 kRad per year.

❑ ~20% degradation in light yield for full mission.







GLAST Calorimeter

Effect of Air Gaps

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Should diodes be strongly coupled with crystal face, or is an air gap adequate?
 - ❑ Crismatec 370 x 30 x 23 mm crystal.
 - Final Tetratek + Al-Mylar wrap.
 - eV5093 preamps and lab electronics.
 - Far end: dual PIN with optical grease.
 - ❑ Near end: dual PIN on fixture that allows varying separation between crystal face and diode face.
 - 5 mm, 3 mm, and 1.5 mm gaps.
 - Dry contact.
 - Optical grease.
- ❑ Gap reduces light by factor of two or more.
- ❑ Must compare against optical grease rather than dry contact!







GLAST Calorimeter

Effect of Air Gaps

Paris Cal Mtg.
14-16 Feb 2000

- ❑ Does polishing or roughening the end face make any difference?
- ❑ Crismatec had finely polished end.
- ❑ Amcryst crystal with polished end.
 1. Polished end, dry contact.
 2. Roughened with 400-grit sandpaper, dry contact. Not shown.
 3. Roughened with 240-grit sandpaper, dry contact.
 4. Optical grease.
- ❑ Roughening the surface does not improve light yield.






GLAST Calorimeter


Position Response of CsI

Paris Cal Mtg.
14-16 Feb 2000

Map of scintillation in 36 cm CsI crystal.

- ❑ Scanned ^{137}Cs source (662 keV).
- ❑ Crystal viewed full-face by PMT (connected with optical grease). Far face was blackened.
- ❑ Side wrap was Tetrtek and aluminized mylar.
- ❑ Scintillation light yield drops by \sim half over length of crystal.
- ❑ Solid line is 42-cm exponential attenuation length.
- ❑ “Hotspot” at \sim 13 cm is real. \sim 2-3% magnitude similar to BaBar hotspots.






Detector Packaging / Light Collection Properties

*Paris Cal Mtg.
14-16 Feb 2000*

- ❑ Study of light collection impact of various crystal wrapping techniques:
 - treatment of CsI block ends vs light output
 - Tyvek, Tetrak, and paints
 - Tyvek & Tetrak laminated with Aluminized mylar
 - laminates attached to crystals with adhesives
 - * Paints are out, laminates show promise
- ❑ Study of compressive load impact on light collection for various wrapping techniques
 - * Short-term loss not significant, longer tests in progress







GLAST Calorimeter

Paints/wraps

*Paris Cal Mtg.
14-16 Feb 2000*


- ❑ Tests conducted on 3x3x6 cm bar with 1 cm² PIN diode.
 - Painting sides reduces light by more than factor of two.
 - Color of paint is irrelevant.
 - Conformal coating before painting is same as painting directly (not shown here).
 - Bare crystal in large Al box gives still less light.
- ❑ Wetting crystal surface is not a good idea: light is piped out.






CsI Light Collection vs. Wrapping Techniques

Paris Cal Mtg.
14-16 Feb 2000




- ❑ 6-cm CsI Detector
- ❑ ^{228}Th source
- ❑ Two wrappings with and without adhesives
- ❑ Again, wetting the crystal surface is not a good idea.






Detector Light Collection Test Unit

Paris Cal Mtg.
14-16 Feb 2000



- ❑ 36 cm detector viewed by PMT
- ❑ Crystal scanned by ^{137}Cs source in Pb collimator
- ❑ Compression controlled by regulator and high pressure Nitrogen






GLAST Calorimeter

Long-term Pressure Tests

Paris Cal Mtg.
14-16 Feb 2000


36-cm crystal, Tetratek and mylar wrap,
held under pressure and scanned.

- ❑ >50 days of 10-g load on all surfaces.
 - All curves normalized to first measurement.
- ❑ Light yield decreases under pressure.
- ❑ Light yield stabilizes after ~10 days at ~5 - 15% loss.
- ❑ Pressure increased to 23 g.
- ❑ Light yield rapidly stabilizes at an additional ~3% loss.



Naval Research Lab
Washington DC





GLAST Calorimeter


End Treatments: White Mask

Paris Cal Mtg.
14-16 Feb 2000

32-cm crystal scanned with ^{22}Na .


- ❑ All surfaces polished. Tetratex wrap.
- ❑ Viewed by PMT with air gap.
- ❑ Near face masked with Tyvek.
- ❑ Two masks, different apertures:
 - Size and location of large PIN.
 - Size and location of small PIN.
- ❑ Light tapering is independent of aperture size.
- ❑ Attenuation length (beyond 10 cm)

$\lambda = 110 \text{ cm.}$



Naval Research Lab
Washington DC





GLAST Calorimeter


End Treatments: Black Mask

Paris Cal Mtg.
14-16 Feb 2000

32-cm crystal scanned with ^{22}Na .


- ❑ All surfaces polished. Tetrak wrap.
- ❑ Viewed by PMT with air gap.
- ❑ Near face masked with black paper.
- ❑ Two masks, different apertures:
 - Size and location of large PIN.
 - Size and location of small PIN.
- ❑ Light tapering is independent of aperture size.
- ❑ Attenuation length (all crystal)

$$\lambda = 75 \text{ cm.}$$



Naval Research Lab
Washington DC





GLAST Calorimeter

Black or White Ends?

Paris Cal Mtg.
14-16 Feb 2000

□ How does end treatment affect light yield and attenuation?

- 32-cm Crismatec crystal mapped with ^{22}Na source.
- PMT readout with black or white aperture mask ($\sim 1 \text{ cm}^2$ open).

□ Black mask reduces light S to $\sim 2/3$ of white mask.


□ Black mask shortens attenuation length.

$$\lambda = 75 \text{ cm for black}$$

$$\lambda = 110 \text{ cm for white}$$


□ Position resolution scales as λ / \sqrt{S}

- **Black mask gives**
 - 1/3 less light, but
 - 20% better position resolution.



Naval Research Lab
Washington DC






GLAST Calorimeter

Positioning with Light Asymmetry

Paris Cal Mtg.
14-16 Feb 2000


32 cm CsI Bar Position Resolution


Light Asymmetry



Position Resolution

SLAC e^- beam, 2 GeV
 $\Delta E \sim 130$ MeV






GLAST Calorimeter

*Paris Cal Mtg.
14-16 Feb 2000*

Various Beam Test Results

J. Eric Grove






GLAST Calorimeter

MSU Beam Test '98 - He Beam

Paris Cal Mtg.
14-16 Feb 2000


Each End of CsI Block



Light amplitude seen at each end of the 32 cm CsI block as a function of position.

He Beam: 160 MeV/nuc
Energy Deposition: ~150 MeV


Sum of Ends of CsI Block



Sum of signals from both ends of the 32 cm CsI block as a function of position.

Variation with position: $\pm 4\%$





GLAST Calorimeter

Position Resolution, SLAC '97

Paris Cal Mtg.
14-16 Feb 2000

Longitudinal position resolution:

- $\sigma_x = 0.04 \text{ cm} - 0.4 \text{ cm}$.
- $3 \times 3 \times 19 \text{ cm}$ crystals.


Position resolution is a function of:

- Slope of asymmetry measure;
- Energy deposited in crystal;
- Shower multiplicity;
- Transverse development of shower.

Light attenuation length:


$$x = \lambda \times (R-L) / (R+L)$$

$$\lambda = 40 \text{ cm} - 120 \text{ cm}.$$



Naval Research Lab
Washington DC






GLAST Calorimeter

SLAC Beam Test 97


Paris Cal Mtg.
14-16 Feb 2000

For a given CsI bar, position resolution does indeed scale roughly as $1/\sqrt{E}$.



Naval Research Lab
Washington DC





GLAST Calorimeter

CERN Beam Test '98

Paris Cal Mtg.
14-16 Feb 2000

